

# **EPAGE**

## **NOZZLE CLEANING PROCEDURES**


### **STEP # 1**

TURN WASHER OFF AND SQUEEZE TRIGGER GUN TO RELIEVE ANY TRAPPED PRESSURE. REMOVE NOZZLE FROM END OF LANCE.



### **STEP # 2**

USING A SMALL PIECE OF WIRE OR A TIP CLEANER FROM AN ACETYLENE TORCH. CAREFULLY INSERT IT INTO THE END OF THE NOZZLE FORCING ANY OBSTRUCTION OUT.



### **STEP # 3**

BACK FLUSH WITH WATER. USING BLUE LOCTITE OR TEFLON TAPE REASSEMBLE THE NOZZLE TO THE LANCE.

